



PARTS LIST

NO.	DEXCRIPTION	QTY	NO.	DEXCRIPTION	QTY	NO.	DEXCRIPTION	QTY
1	O-ring	1	17	Safety valve	1	33	Press spring	2
2	Tank nut	1	18	Relief valve spring	1	34	Pump outer case	2
3	Washer	2	19	Regulate bolt	1	35	Pump cover	2
4	O-ring	2	20	O-ring	2	36	Pin 4×30	2
5	Ram	1	21	Seal bolt	2	37	Release assembly	1
6	Ram header	1	22	Ball	2	38	O-ring	1
7	Pin 4×35	1	23	Ball	2	39	Ball	1
8	O-ring returner	1	24	Separator	2	40	Washer	1
9	O-ring	1	25	Ball	2	41	O-ring	2
10	Retaining ring	1	26	High pressure bolt	2	42	Pump core	1
11	Cylinder outer case	1	27	Washer	1	43	Pump case	1
12	O-ring	1	28	O-ring	2	44	Regulate bolt	1
13	Seal bolt	1	29	Sealing washer	2	45	O-ring	1
14	Cylinder	1	30	Pump core	1	46	Relief valve spring	1
15	O-ring	1	31	Pump case	1	47	Safety valve	1
16	Valve base	1	32	Pump inner case	2	48	Washer	1