



- Onderdelen -
- Spare parts -
- Pièces de rechange -
- Ersatzteile -



Y420330

Part	Description	Qty	Part	Description	Qty
Y420330-1	Retaining Ring	2	Y420330-21	Set Screw	1
Y420330-2	Washer	2	Y420330-22	Retaining Ring	1
Y420330-3	Front Wheel	2	Y420330-23	Upper Handle	1
Y420330-4	Frame	1	Y420330-24	Handle Cover	1
Y420330-5	Rear Caster Assembly	2	Y420330-25	Screw	1
Y420330-6	Washer	4	Y420330-26	Lower Handle	1
Y420330-7	Screw	4	Y420330-27	Hydraulic Unit	1
Y420330-8	Washer	4	Y420330-28	Spring	2
Y420330-9	Screw	4	Y420330-29	Pin	1
Y420330-10	Rubber Bumper	2	Y420330-30	Hydraulic Adaptor	1
Y420330-11	Tie Rod	2	Y420330-31	Retaining Ring	2
Y420330-12	Bolt	2	Y420330-32	Lift Arm Shaft	1
Y420330-13	Washer	2	Y420330-33	Bolt	2
Y420330-14	Washer	4	Y420330-34	Retaining Ring	2
Y420330-15	Nut	2	Y420330-35	Nut	2
Y420330-16	Screw	4	Y420330-36	Lift Arm Assembly	1
Y420330-17	Cover Plate	1	Y420330-37	Retaining Ring	2
Y420330-18	Shaft	1	Y420330-38	Saddle	1
Y420330-19	Handle Socket Roller	1	Y420330-39	Saddle Screw	1
Y420330-20	Handle Socket	1	Y420330-40	Rubber Saddle Pad	1

- Onderdelen -
- Spare parts -
- Pièces de rechange -
- Ersatzteile -



Y420330-PU

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
Y420330-PU1	Tank Nut	1	Y420330-PU22	O-ring	2
Y420330-PU2	O-ring	1	Y420330-PU23	Sealing washer	2
Y420330-PU3	Washer	1	Y420330-PU24	Pump core	1
Y420330-PU4	Ram	1	Y420330-PU25	Press spring	1
Y420330-PU5	Ring	1	Y420330-PU26	Pump outer case	1
Y420330-PU6	Ring washer	1	Y420330-PU27	Pump cover	1
Y420330-PU7	O-ring returner	1	Y420330-PU28	Ring	1
Y420330-PU8	O-ring	1	Y420330-PU29	Safety valve	1
Y420330-PU9	Cylinder outer case	1	Y420330-PU30	Relief valve spring	1
Y420330-PU10	Seal bolt	3	Y420330-PU31	Washer	1
Y420330-PU11	O-ring	3	Y420330-PU32	Pump case	1
Y420330-PU12	Cylinder	1	Y420330-PU33	O-ring	2
Y420330-PU13	Washer	1	Y420330-PU34	Sealing washer	2
Y420330-PU14	Washer	1	Y420330-PU35	Pump core	1
Y420330-PU15	Ball	5	Y420330-PU36	Press spring	1
Y420330-PU16	Valve base	1	Y420330-PU37	Pump outer case	1
Y420330-PU17	Safety valve	1	Y420330-PU38	Pump cover	1
Y420330-PU18	Relief valve spring	1	Y420330-PU39	Ring	1
Y420330-PU19	Regulate bolt	2	Y420330-PU40	Release assembly	1
Y420330-PU20	Washer	1	Y420330-PU41	Ball	1
Y420330-PU21	Pump case	1			